


PHENOLIC
TRIM SHOE INSTALLATION
6.5A



SHOWN FOR BOTTOM SHOE
(INVERT FOR CEILING HUNG SHOE)

1. SELECT APPROPRIATE LENGTH SHOE FACES AND 2 SHOE ENDS.
2. INSERT 1 SHOE END INTO SIDES OF FACES AS SHOWN (NOTE LARGE HEM POSITION), MAKING A THREE SIDED BOX.
3. POSITION THIS BOX AROUND PILASTER.
4. SLIDE REMAINING END INTO THE OPEN SIDE OF THE SHOE FACES
5. ATTACH SHOE ENDS TO PILASTER USING #14 x 3/4 TAMPER RESISTANT SCREWS.

NOTE:
FOR PILASTER AGAINST A WALL
ATTACH ONE SHOE END TO THE
PILASTER BEFORE ASSEMBLY
INTO THE WALL BRACKETS

NOTE:
INSERTION OF THE SCREWS CAN
BE FACILITATED BY PRE-DRILLING WITH
A 7/32 DIA. DRILL.

REV 12/04